

Title: Lisbon three-phase inverter installation

Generated on: 2026-02-24 23:22:21

Copyright (C) 2026 B&K BESS. All rights reserved.

---

Some three phase inverter models can be installed horizontally (above 10°; tilt) as well as vertically, and at any tilt over 10°; up to 90°;.

Be sure the length of all battery cables is the same. Otherwise, there will be voltage difference between inverter and battery to cause parallel inverters not working.

Choose an installation position, the wall must be firm and reliable. Remove the bracket of the product. Fix the bracket with the expansion screws in the package. Place the product on the ...

During installation, testing and inspection, adherence to all the handling and safety instructions is mandatory. Failure to do so may result in injury or loss of life and damage to the equipment.

Website: <https://bktrucking.pl>

